


# FIREFLY™

## Replacement Kit Instructions

Replacing your Firefly rotors is easy.

Follow these instructions and you will be back in the air in no time!



## Component List

- ① 1-Top Rotor.
- ② 1-Bottom Rotor (long stem).
- ③ 2-Rubber Stoppers.
- ④ 2-Spacers.

## Instructions


Slide the bottom rotor (long stem) down the drive shaft.

Slide down 1 of the supplied spacers. Next slide the top rotor down the drive shaft.

Then, supporting the bottom the drive shaft slide the small stopper on the top to hold the rotor assembly together.

Squeeze all components together.

Keep instructions for future reference.



## To replace the tail fin:

- 1) Remove old fin completely.
- 2) Stand replacement fin vertically in the same position as the original fin.
- 3) Wrap Mylar around the tail-boom and adhere to new tail fin as shown.

Contact us: [www.interactivetoy.com](http://www.interactivetoy.com) or call: 1-866-214-2220

### Limited 30-day warranty

This product is warranted by Interactive Toy Ltd. against manufacturing defects in material and workmanship under normal use for thirty (30) days from the date of purchase.